

USB Wifi Adapter

for IPTV 2.2



Quick Set-up Guide



▶STEP 6

You will be prompted to enter your WiFi Password



▶STEP 7

Enter your WiFi Password. Click EXIT when done.



▶STEP 8

Click OK when done.



▶STEP 9

Connection progress will appear.



▶STEP 10

Successful connection will indicate "AUTO" next to your WiFi Network.



▶STEP 11

You are now using WiFi and can start viewing your Kapamilya shows!



IPTV 2.2 - USB WiFi ADAPTER w/ ANTENNA

Say goodbye to long cables! Now you have the option to connect your IPTV 2.2 Set Top Box through the USB WiFi Adapter.

NOTE: Quality of video is still better for LAN connection; WiFi performance varies greatly depending on location, interference and other factors based on your local environment. The ability to stream hi-definition video depends on the bit rate of the video and your local WiFi performance.

FEATURES

- Portable, compact, pocket sized design
- External 5DBI omnidirectional antenna provides stable wireless signal transfer
- 150 Mbps wireless transmission rate for both transmit & receive
- Seamlessly compatible with 802.11 b/g/n devices
- Supports WPS key encryption
- Supports 64/128 WEP, WPA/WPA2/WPA-PSK/WPA2/WPA2-PSK encryption methods
- Supports 802.1x security authentication standards
- Friendly user configuration and diagnostic utilities.

TECHNICAL SPECIFICATIONS

Standards	IEEE 802.11n, IEEE 802.11g, IEEE 802.11b
Wireless Signal Rates With Automatic Fallback	11g: Up to 54Mbps(dynamic) 11n: Up to 150Mbps(dynamic) 11b: Up to 11Mbps(dynamic)
Frequency Range	2.4-2.4835GHz
Wireless Transmit Power	17dBm(MAX EIRP)
Modulation Type	OFDM/CCK/16-QAM/64-QAM
Support Operating System	Win XP/Vista/Win 7/Linux/MAC.OS
Interface	USB2.0 Hi-Speed connector
Certifications	CE, FCC
Operating Temperature	0°C~40°C(32°F~104°F)
Storage Temperature	-40°C~70°C(-40°F~158°F)
Relative Humidity	10% ~ 90%,non-condensation
Storage Humidity	5%~95%,non-condensation

Your USB WiFi Installation Guide

▶STEP 1

Connect the WiFi to the Set Top Box. The WiFi dongle can be connected on the available USB ports found on the side of the Box or behind the Box



▶STEP 2

Using your Remote Control, press "MENU" and enter **PASSWORD "0000"**




▶STEP 3

Select "NETWORK"



▶STEP 4

Select "WiFi". Available WiFi Networks will appear. Click **GREEN Button** on Remote Control to RESCAN



▶STEP 5

Select your WiFi Network

